

★ COMBAT ARMS EARPLUGS ★

PRESS THE ROCKER SWITCH COVER TO SELECT THE TYPE OF HEARING PROTECTION NEEDED.

1 To protect your hearing from weapons fire, **press the rocker switch cover to the OPEN position** (see picture). Speech and background noise will sound clear, but your hearing is protected from weapons fire.

2 To protect your hearing from continuous noise, such as from aircraft, vehicles, generators, or watercraft, **press the rocker switch cover to the CLOSED position**. The rocker switch cover will be flat (see picture).

USE AND CARE:

- Check for proper fit by gently tugging on each earplug. You will feel some tension.
- Adjust the rocker cover to desired position.
- **Gently remove earplugs** to avoid causing eardrum injury.

cover open

1


for weapons fire

cover shut (flat)

2

for constant noise

- **Clean earplugs with soap and water** and keep the filter holes free of ear wax and other debris.
- **Return dry earplugs** to the carrying case or tie the connector cord to your helmet or load bearing gear for ready access.



Suggested Size Distribution for Ordering:

20% = Small (O.D. Green): 6515-01-576-8837

70% = Regular (Desert Tan): 6515-01-576-8861

10% = Large (Coyote Brown): 6515-01-576-8869

Note: Younger populations (basic training) may require smaller sizes and some users will need a different size for each ear.

For More Information contact the Army Hearing Program at 410-436-3797, DSN 584-3797.