

## FOR MAXIMUM PROTECTION AND COMFORT, INSERT COMBAT ARMS EARPLUGS AS FOLLOWS:

Press the rocker switch cover to select the type of hearing protection needed.

- 1** To protect your hearing from weapons fire, press the rocker switch cover to the OPEN position (see picture). Speech and background noise will sound clear, but your hearing is protected from weapons fire.
- 2** To protect your hearing from continuous noise, such as aircraft, vehicles, generators, or watercraft, press the rocker switch cover to the CLOSED position. The rocker switch cover will be flat (see picture).

### USE AND CARE:

- Check for proper fit by gently tugging on each earplug. You will feel some tension.
- Adjust the rocker cover to the desired position.
- Gently remove earplugs to avoid eardrum injury.
- Clean earplugs with soap and water and keep the filter holes free of ear wax and other debris.
- Return dry earplugs to the carrying case or tie the connector cord to your helmet or load bearing gear for ready access.



Cover open for weapons fire



Cover shut (flat) for constant noise



#### Suggested Size and Distribution for Ordering

20% = Small (O.D. Green) 6515-01-576-8837

70% = Regular (Desert Tan) 6515-01-576-8861

10% = Large (Coyote Brown) 6515-01-576-8869

